



SMART
POWER
DESIGN

SIDE AIR INTAKE SCOOP SMART FORTWO 451

User Manual | Smart Power Design

Side Air Intake Scoop Smart Fortwo 451



Photo 1: The Side Air Intake Scoop for Smart Fortwo 451 by Smart Power Design

1. Clean well the part where we will be placed the Side Air Intake Scoop.
2. Remove the protective tape and place it in the right place and push hard.
3. You are ready! Installation completed.
4. Do not wash the Smart car for a day.



Side Air Intake Scoops in other colors

Enjoy what you have just installed. We hope that you are not going to like it but to love it as it fits perfectly on your lovely Smart Fortwo 451.



We would like to thank you for purchasing from Smart Power Design a company specialized in Smart Tuning and Accessories.

If you have any problem or questions feel free to contact us via email at: info@smart-power-design.de or sales@smart-power-design.com or via telephone at: 0049-711-217-20291.



Company Information

Smart Power Design
Möhringer Str. 93 – Stuttgart
Zip: 70199 – Germany

Email: info@smart-power-design.de
sales@smart-power-design.de

Telephone: 0049 711 217 20291

Website: www.smart-power-design.de

Follow us

